


INSTALLATION INSTRUCTIONS OF ROTATING SHOE RACK




viyar

0 (800) 100 100 | viyar.eu

RELIABLE FITTINGS ARE DURABLE FURNITURE


INSTALLATION OF DOWN SLIDE

1. Refer to below drawing, pre-drilling the holes with $\varnothing 2,5$ drill, then lock the slide with ST4*16 screws.




INSTALLATION OF UPPER SLIDE

1. Refer to below drawing, pre-drill the holes with $\varnothing 2.5$ drill, then lock the slide with ST4*16 screws.




FIXING THE FRAME




1. Fixing upper slide

Fixing the upper slide with 6*20*M5 screw according to the reference picture on the right;





2. Fixing down slide

Fixing the down slide with 6*20*M5 screw according to the reference picture on the right;




3. Adjustment

After completing above steps, fix the height by locking telescopic pole with M4*16 screw according to the reference picture on the right, then put on the decorative cover following the arrow direction.



4. Installation of layer plate

After completing above steps, fasten the layer plates as the reference picture above.



Completion

